



Our 10" Dual Fan Brush Head uses mono-filament bristles and offers 2 different jets for maximum cleaning power.

To switch between the two jets, simply disconnect the hose from the Y-Splitter and reconnect it to the alternate Y-Splitter - This will allow you to change your water flow. The 4 jets cannot all be used simultaneously.



Y-Splitters

Alternate hose between the two to change jet mode.



The pencil jet delivers a concentrated stream of water and are more effective for scrubbing and removing stubborn dirt.



The fan jet distributes water in a wide, flat stream and is better for rinsing and covering larger areas.